

Motomon's Tiny [GC-101] Quick Reference Guide



Important Operational Notes

All commands use default username & password. (“username“/“0000“)

All commands have to be sent via SMS to Tiny's SIM card phone number.

GPRS service has to be activated & enabled for use with SIM cellular service provider.

Commands can be sent from any cellular phone capable of sending SMS.

GC-101 has to have a SIM card installed properly and has to be locked onto a GSM network.

It is strongly advised to test the SIM card with a regular phone before using it in the GC-101.

Always answer Panic calls, if not the call will go to voice mail and eat up your minutes on the SIM card.

Turn unit off when not needed, unit will boot up very quickly when turned on.

After SOS is acknowledged Deactivate unit in Panic Mode [**#username,0000,offpanic***] or it will keep

sending Panic messages. To avoid critical communication breakdown, Always know how much data,

minutes, and sms messages you have available on your SIM card! Setting up additional Alerts and

Tracking are done from website: www.motomon.com, login.

Motomon's Tiny [GC-101] Quick Reference Guide (cont.)

Basic communication setup

Programming APN name to “wap.cingular“ (AT&T US):

#username,0000,3,wap.cingular,.*

Selecting UDP communication protocol:

#username,0000,14,9*

Setting up server's IP address:

#username,0000,18,194.213.214.60:1500*

Selecting buffer operational mode to buffer X number of samples before sending them out:

#username,0000,21,2*

Setting up the required number of samples taken before sending them out. (3 samples before sending):

#username,0000,20,3*

Setting up how fast you want to collect samples (1 sample in 30s / unlimited number of samples):

#username,0000,6,30,9999*

Switching between UDP and TCP/IP protocol

TCP/IP

#username,0000,18,194.213.214.60:1400*

#username,0000,14,7*

UDP

#username,0000,18,194.213.214.60:1500*

#username,0000,14,9*

Motomon's Tiny [GC-101] Quick Reference Guide (cont.)

Other Useful Commands

Setting up SOS phone number – number will be called when SOS button pressed

#username,0000,sosphone,+13051231456*

Find out what IMEI your Tiny have

#username,0000,imei*

Command GC-101 to send its position data to server immediately

#username,0000,10*

Setup Phone List - 1st phone number is the number where all the warnings are sent!!!

#username,0000,5,+13051111111,+13052222222,+13053333333*

Deactivate Panic Mode (to stop GC-101 from continuing sending emergency reports out)

#username,0000,offpanic*

Switching SOS beep OFF

#username,0000,19,0*

Switching SOS beep ON

#username,0000,19,1*

Changing username

#username,0000,1,newusername*

Changing password (“0000“ is the old password and “1111” is the requested new password)

#username,0000,2,1111,1111*

Activate voice monitoring mode (after calling into GC-101 it is possible to listen in)

#username,0000,8,1*